

Chapter E 353

MULTI-OUTLET ASSEMBLY

E 353.01 Other articles
E 353.02 Use

E 353.03 Metal multi-outlet assembly through dry partitions

E 353.01 Other articles. Installations of multi-outlet assembly shall comply with applicable provisions of Wis. Adm. Code chapter E 300. See definition in chapter E 100.

History: Cr. Register, January, 1968, No. 145, eff. 2-1-68.

E 353.02 Use. Multi-outlet assembly may be installed in dry locations. It shall not be installed (1) where concealed, except that the back and sides of metal multi-outlet assembly may be surrounded by the building finish; (2) where subject to severe physical damage unless approved for the purpose; (3) where the voltage is 300 volts or more between conductors unless assembly is of metal having a thickness of not less than .040 inches; (4) where subject to corrosive vapors; (5) in hoistways nor (6) in any hazardous locations.

History: Cr. Register, January, 1968, No. 145, eff. 2-1-68.

E 353.03 Metal multi-outlet assembly through dry partitions. Metal multi-outlet assembly may be extended through (not run within) dry partitions, providing arrangements are made for removing the cap or cover on all exposed portions and no outlet is located within the partitions.

History: Cr. Register, January, 1968, No. 145, eff. 2-1-68.